



# STROBE TUBE AND LAMP IDENTIFICATION CHART

## Incandescent



K149123A    K8107A041    K8107181A    K8107185A    K8107194A    K8107236A    K8444A173A    K8442A039    K8107A130

## Strobe Tubes



K149122B    K149128A    K149130A    K8107159A    K8107177A    K8107178A    K8107215A    K8107251A

## Krypton

Part	Status	Model and Revision	Lamp	Notes
K8107185A	Active	MSL	Incandescent	
K8107215A	Active	BPL	Strobe	
K8107236A	Active	121A	Incandescent	
K8107251A	Active	121S Rev C	Krypton	
K8442A039	Active	371	Incandescent	
K8107A130	Active	371L	Incandescent	
K8107041	Active	121X 24V	Incandescent	
K8444A173A	Active	121X 120V	Incandescent	
K149122B	Active	151XST, 154XST, 371ST	Strobe	
K149123A	Active	225, 225X, AV1 120V	Incandescent	
K149128A	Active	141ST, VALS, LP1	Strobe	Not replaceable in units built before 1993
K149130A	Active	AV1ST, LP3, LP6	Strobe	
K8107159A	Active	27XST Rev. C1, C2, D, FSEX	Strobe	Strobe tube, wires and connector assembly
K8107177A	Active	FB2PST Rev. A4, A5, B, FB2PSTX, 225XST, 224XST, WV450X	Strobe	
K8107178A	Active	131DST, 131ST, 400ST, 27XST Rev. C, 371DST	Strobe	
K8107181A	Active	121S Rev. A,B, 400 120V	Incandescent	
K8107210A	Active	LITESTAK®, AV1 24V	Incandescent	
K8107194A	Active	LITESTAK® 120V	Incandescent	
K8107A149A	Active	LITESTAK® 240V	Incandescent	